



Fill-Rite® Cabinet Pump & Cabinet Meter Kits

KIT305FP	KIT, FACEPLATE	0-89404-21532-6	
KIT305SV	KIT, SOLENOID VALVE	0-89404-21531-9	
KIT702FP	KIT, FR702 OLD FACEPLATE & FASTENERS	0-89404-21568-5	
KIT702VELRUFPP	KIT, FR702VELRUFPP FACEPLATE	0-89404-21573-9	Faceplate, 2 Screws, Cover
KIT702VLRUFPP	KIT, FR702VLRU FACEPLATE	0-89404-21572-2	Faceplate, 2 Screws, Cover
KIT702VRFP	KIT, FR702VR FACEPLATE	0-89404-21569-2	Faceplate, 2 Screws, Cover
KIT702VRGUFPP	KIT, FR702VRGU FACEPLATE	0-89404-21571-5	Faceplate, 2 Screws, Cover
KIT702VRUFPP	KIT, FR702VRU FACEPLATE	0-89404-21570-8	Faceplate, 2 Screws, Cover
KIT902CC	KIT, FR902 CLEAR COVER	0-89404-21536-4	
KIT902HA	KIT, SWITCH HANDLE ASSEMBLY	0-89404-21535-7	
KIT902LRFP	KIT, FR902LR FACEPLATE	0-89404-21527-2	Faceplate, 2 Screws, Cover
KIT902LRUFPP	KIT, FR902LRU FACEPLATE	0-89404-21529-6	Faceplate, 2 Screws, Cover
KIT902LS	KIT, 902 LINE SWITCH	0-89404-21525-8	4 - Pole Line Switch, 2 Screws
KIT902MB	KIT, FR902 MOUTING BRACKET	0-89404-21534-0	
KIT902RFP	KIT, FR902R FACEPLATE	0-89404-21526-5	Faceplate, 2 Screws, Cover
KIT902RUFPP	KIT, FR902RU FACEPLATE	0-89404-21528-9	Faceplate, 2 Screws, Cover
KIT902SV	KIT, REPAIR, 902 SOLENOID VALVE ASSY KIT	0-89404-21524-1	Solenoid Subassembly, Gasket, 4 Screws